

DUAL WORKSTATION MONITOR

61-200-0012

Versatile continuous monitor specifically designed for those price-sensitive customers.

- Based on a unique, accurate, low-voltage, resistive loop detection technology.
- Being manufactured by precision SMT technology along with its compact stainless steel housing
- Able to sustain supreme reliability
- Can monitor the grounding of 2 operators and/or 2 ESD mats (100M)

Product Specifications

- Monitor 2 operators, 2 ESD mats, 2 machines independently.
- 3-color LED to indicate status of operator wrist-strap: HIGH, LOW, SAFE.
- Audio and LED will give alarms when monitor detects problems on grounding.
- Audio alarm volume is user adjustable with maximum of 85dB typical.
- Normal voltage when wearing wrist-strap is 100mV.
- Maximum mat voltage : 900mV

Maximum machine voltage and current (Hard Grounding) : 50mV, 0.2m

